



### 1- MONTAJE DE LA LUMINARIA LUMINAIRE INSTALLATION MONTAGE DU BLOC

### 2- MONTAJE EN SUPERFICIES IRREGULARES INSTALLATION ON IRREGULAR SURFACES MONTAGE SUR SURFACES IRREGULIERES

Tornillos autorroscantes 4x20  
4x20 or similar self-tapping screws  
vis autofiletantes 4x20 ou similaires

### 3- CONEXIÓN ELÉCTRICA Y TEST ELECTRICAL CONNECTION AND TEST BRANCHEMENT ÉLECTRIQUE ET TEST

TELEMANDO (+ -)  
REMOTE CONTROL (+ -)  
TELECOMMANDE (+ -)

(230 V - 50 HZ)

230V-50Hz

TMU-300  
TMS-050

Las luminarias LDFxxx0C no tienen conexión de telemando  
LDFxxx0C luminaires have no remote control connection  
Les blocs LDFxxx0C n'ont pas de connexion télécommande

Botón de encendido  
ON button  
Bouton allumage

Botón de apagado  
OFF button  
Bouton extinction

Permanente / Maintained / Permanent

"ON" Permanente, "OFF" NO Permanente  
"ON" Maintained, "OFF" NON Maintained  
"ON" Permanent, "OFF" NON Permanent

### 4- DESMONTAJE DE LA LUMINARIA LUMINAIRE DISMANTLING DEMONTAGE DU BLOC

- Retirar la luminaria de la preplaca presionando con un destornillador sobre la pestaña
- Remove the luminaire out of the plate pressing with a screwdriver in the claw
- Retirer le bloc de la pré-plaque en introduisant un tournevis dans la griffe

OK

Model	Length	Light Source	Life
LDF-3050C	50 in	LED	1h
LDF-3070C	75 in	LED	1h
LDF-3100C	100 in	LED	1h
LDF-3150C	150 in	LED	1h
LDF-3200C	225 in	LED	1h
LDF-3300C	315 in	LED	1h
LDF-3400C	400 in	LED	1h
LDF-3500C	500 in	LED	1h
LDF-3100CP	100 in	LED	1h
LDF-3150CP	150 in	LED	1h
LDF-3200CP	225 in	LED	1h
LDF-3300CP	315 in	LED	1h
LDF-3400CP	400 in	LED	1h
LDF-3500CP	500 in	LED	1h
LDF-3150CP2	150 in	LED	2h
LDF-3200CP2	200 in	LED	2h
LDF-3300CP2	325 in	LED	2h
LDF-3400CP2	400 in	LED	2h
LDF-3150CP2	150 in	LED	3h

### MARCAJO DE LA LUMINARIA LABELLING OF THE LUMINAIRE MARQUAGE DU LUMINAIRE

Model	Length	Light Source	Life
LXF-3100CP	100 in	LED	1h
LXF-3100FCP	100 in	LED	1h
LXF-3150CP	150 in	LED	1h
LXF-3150FCP	150 in	LED	1h
LXF-3200CP	200 in	LED	1h
LXF-3200FCP	200 in	LED	1h
LXF-3300CP	315 in	LED	1h
LXF-3300FCP	315 in	LED	1h
LXF-3400CP	400 in	LED	1h
LXF-3400FCP	400 in	LED	1h
LXF-3150CP2	125 in	LED	2h
LXF-3150FCP2	125 in	LED	2h
LXF-3300CP2	300 in	LED	2h
LXF-3300FCP2	300 in	LED	2h

X: Autónoma / Self contained / Appareil autonome

0: No permanente / Non maintained / Non permanent  
1: Permanente / Maintained / Permanent

B: Posibilidad de puesta en reposo a distancia  
With setting of the state mode with remote control.  
Avec mise en état de repos à distance

E: LED o baterías no reemplazables  
LEDs or batteries, not replaceable  
LED ou des batteries, et non remplaçables

50/120/180: Autonomía nominal en minutos  
Nominal duration of the luminaire (in minutes)  
Autonomie nominale du luminaire en minutes

Curvas bajo solicitud  
Curves under request  
Courbes sur demande

**(ES)** - TIEMPO DE CARGA: 24 h  
- TELEMANDO: Con un Telemando Mod. TMS 050 ó TMU 300 (no suministrado), instalado según el esquema de conexión, este aparato puede pasar del estado de Emergencia al de Reposo (sólo con red ausente).

**(EN)** - CHARGING TIME: 24 h  
- REMOTE CONTROL: With a Remote Control Mod. TMS-050 ó TMU 300, installed according to the above design, the luminaire can change from an emergency mode to rest mode (only with Mains supply).

**(FR)** - DUREE DE CHARGE: 24 h  
- TELECOMMANDE: Avec une Télécommande Mod. TMS-050 ó TMU 300, installé selon le schéma, cet appareil peut passer de l'état de veille à l'état de repos (uniquement avec le Secteur absent).

**TEST DE CONMUTACIÓN Y DE FUNCIONAMIENTO DE LÁMPARAS CON PRESENCIA DE RED (TEST ZC):** Test General: Mediante Telemando Mod TMS-050 ó TMU 300, conectado según el esquema

**-CAMBIO DE BATERÍAS:** Las baterías deben reponerse cuando la autonomía no es conforme con la duración asignada. NOTA: Con el fin de alargar la vida de las baterías es conveniente realizar descargas periódicas completas (desconectando alimentación de red) al menos cada 10 semanas. Las baterías solo pueden ser reemplazadas por personal cualificado.

**-BATTERIES REPLACEMENT:** Batteries must be replace when autonomy is below the declared one. NOTE: In order to improve the batteries life it is convenient to make periodical complete discharges (disconnecting the mains supply) at least every 10 weeks. The battery can only be replaced by qualified personnel.

**-NOTE:** Light source: LED - Non replaceable

**-NOTE:** Source lumineuse: LED - non remplaçable